


## **INDOOR ACCESS HUB**

Instruction manual for Sensorberg's  
indoor access hub


Also online in:  
[documents.sensorberg.com](https://documents.sensorberg.com)





### **ACCESS HUB**


Our flagship access control device, used for access control, management and monitoring. Provides access via Bluetooth and LAN, with modular NFC and touch-button.

## INSTALLATION PREREQUISITES

- 

1 Cat 5e (or higher) cable with POE+
- 

2 POE+ switch installed in server room with separated VLAN for Sensorberg devices.
- 

3 Flush Socket in wall, next to the door. ~125 cm height
- 

4 e-opener  
or  
Electrical lock

Compatible lock (12V e-opener or potential free opening contact for electric lock)

## INSTALLATION MATERIALS

- 

5 Housing screws x2
- 

6 Access Hub case

Front Back
- 


7 Security screw x1
- 

8 Access Hub

3.0 or 3.1 for power 24/7

## BEFORE YOU INSTALL


1




INSIDE




WALL




OUTSIDE (INDOOR)



INSTALLATION GUIDE






INSIDE

WALL







OUTSIDE (INDOOR)




INSIDE

WALL

OUTSIDE (INDOOR)






INSIDE

WALL

OUTSIDE (INDOOR)



INSIDE

WALL

OUTSIDE (INDOOR)

