

BUILDING HUB

Instruction manual for Sensorberg's Building Hub

Also online in: documents.sensorberg.com

For more info: support@sensorberg.com



BUILDING HUB

Our standard device controller, the Building Hub, manages our access control devices and connects them securely to our wider infrastructure.

INSTALLATION PREREQUISITES



POE+ switch installed in server room with separated VLAN for Sensorberg device.

INSTALLATION MATERIALS




Building Hub




Short patch cable for connecting the Building Hub to the switch.

*Not included in the installation package.



SERVER ROOM

STEP 1





SERVER ROOM

There are 2 options to fix the Building Hub in the wall or in another location of your choice:


Option 1



Option 2



SERVER ROOM



SERVER ROOM

