


## **LOCK CONTROL HUB**

Instruction manual for Sensorberg's  
Lock Control Hub installation for lockers


Also online in: [documents.sensorberg.com](https://documents.sensorberg.com)  
For more info: [support@sensorberg.com](mailto:support@sensorberg.com)



## **LOCK CONTROL HUB**

Our Lock Control Hub is built to power, monitor, and manage up to 32 devices. These can include digital locks, self-storage boxes, motion detectors, bike stations, and more.

## INSTALLATION PREREQUISITES



Cat 5E (or higher) cable with POE+




PoE+ switch installed in server room with separated VLAN for Sensorberg devices.




Make sure to have the Building Hub installed in the Server room (With Ethernet and power cable).

2 Lockers or Storage boxes




## INSTALLATION MATERIALS



3

Molex

RJ45




5

Electrolock (Lock holder)




7

Electrolock (Lock catch)




4

AC Adapter



6

Lock Control Hub




8



Round head screw



\* x4

\* Not included in the installation package from Sensorberg, as wall texture and required material varies from project to project.


## STEP 1







STEP 6



STEP 7

