



## HOW TO MEASURE THE CYLINDER LENGTH

### Step 1

**Measure the outside dimension of the cylinder.** It is measured from the outside of the door fitting to the cuff screw. The measurement can be carried out with a standard folding rule.

### Step 2

**Measure the inside dimension of the cylinder.** Measure from the inside of the door fitting to the cuff screw.

### Step 3

**Communicate dimensions to Sensorberg.** We will take care of ordering the appropriate digital cylinder.

